

LMS-6 Radiosonde

The LMS-6 Radiosonde is a balloon-launched radiosonde manufactured by Lockheed-Martin Sippican, and used for meteorological sounding.

Contents

Overview

Specs

Photos

Audio Samples

Disassembly

Reassembly

Powering the radiosonde in the lab

Connectors

Components

Notes

GPS Subsystem

CC1050 Subsystem

Test Points

Circuits

- RF Transmitter Circuit
 - Low Pass Filters
 - PA LPF
 - FL101 - CC1050 LPF

- Relative Humidity Circuit
- Analog Multiplexer

Original Firmware

- Option Bytes
- GPIO Initialization
- MCC Initialization
- ADC Configuration
- Interrupts
- GPS Initialization

Modifications

- Disable amplification
- Change Frequency^[1]



LMS-6 Radiosonde found on railroad tracks, circled in red.

Instruction Timing Tables

Ideas for doing AFSK modulation on 70CM with CC1050 and ST7

- FeatherHAB Approach using a similar FSK chip
- SFCW-like Frequency Hopping Approach(RSAXVC)
- Why we're not going to do 9600baud 70CM FSK modulation

ST7 Programming

- FlashBash Programmer
- LMS-6 Card Edge Interface
 - Interface Description and Theory of Operation
 - Circuit Power Options
 - Battery Power
 - USB 5V Power
 - USB to UART
 - In Circuit Programming
 - eFuse

Reference

Overview

There are two models of the LMS-6, a 403MHz model and a 1680MHz model. This article will cover the 403MHz model unless specified.

Specs


- 16 Fixed transmit carrier frequencies (MHz): 400.250, 400.625, 401.000, 401.375, 401.750, 402.125, 402.500, 402.875, 403.250, 403.625, 404.000, 404.375, 404.750, 405.125, 405.500, 405.875
- Frequency tolerance +/-30ppm
- Mean TX Power 70.8mW (18.5dBm)
- Emission Designator 16K8F1D
- FSK with a maximum modulating frequency of 4.8 kHz
- Emission 3dB BW +/-5.0 kHz
- Emission 20dB BW +/-12.7 kHz
- Omnidirectional antenna
- Main beam gain 2dBi
- Horizontal Beamwidth 360 degrees
- Vertical Beamwidth +84 degrees

Source: <https://apps.fcc.gov/els/GetAtt.html?id=121623&x=>.


Photos



Photo of the lower panel of the 403 MHz version of the LMS-6 Radiosode. Of particular note are the DIP Switch configurations for setting the transmit frequency.



Relative Humidity Circuit section



LMS6 Label possibly showing calibration factors.

Audio Samples

The following samples were taken from both frequency versions at a close distance using a HackRF SDR.

Frequency	Audio file
400 MHz	0:00 / 0:24
1680 MHz	0:00 / 0:15

Disassembly

This is a minimally-destructive disassembly method that will allow the payload to be held back together if you wish to reuse the payload for another weather balloon flight.

1. Cut the zip tie holding the plastic strap to the balloon/parachute tether rope.
2. Examine rope, parachute and parachute rigging lines for viability. Neatly organize the flight rigging if usable. Discard if not viable for reuse.
3. Peel open the battery/power cover from the bottom of the radiosonde and ensure that all 3 connectors are loose and not connected to one another.
4. Remove the plastic pins from either side of the radiosonde.
5. Peel away the paper wrapper starting with the corner near the external sensors
6. Tear the plastic strap off. It's held on mostly with a few staples into the styrofoam
7. Using a sharp utility razor, cut the bottom half of the shell off, carefully. The styrofoam is about 0.6 inch (15mm) thick on both the sides and bottom, so making a long cut all the way around the sides of the radiosonde, about 0.75" from the bottom edge, and not much deeper than 0.6" is recommended. You can use the exit of the weather sensors as a guide. DO NOT fully separate the radiosonde styrofoam shell yet.
8. Cut the tape holding the antenna into its dipole shape. Completely remove the tape and straighten the antenna wires.
9. Peel open the battery terminal access panel on the bottom again. Using a pair of tweezers, remove the small styrofoam block keeping the power wires restrained.
10. Push the battery wires through the hole as you peel apart the styrofoam shell.
11. The shell is glued together from the factory. Some of this glue will hold wires to the styrofoam shell. Carefully peel the sensor wires away from the foam and carefully pull the antenna wire (straightened in step 8) through the hole in the bottom of the shell.
12. The board should be completely separated from the two styrofoam shell halves. Set aside shell, plastic strap, plastic pins and paper wrap for possible re-use later.
13. Remove (3) Lithium CR-123A cells from the battery holders and discard of them safely.



Partially-disassembled LMS-6 Radiosonde, with upper styrofoam shell removed. Some RF shielding removed. Rechargeable cells in use for testing purposes.

Reassembly

1. Place fresh lithium CR-123A cells into the battery holders. Use of rechargeable cells is not recommended for high-altitude flight.
2. Pass antenna wire through bottom part of shell.
3. Pass all 3 power wires through the bottom part of shell and into the power lead compartment.
4. Make sure radiosonde circuit board is properly aligned and seated into the bottom half of the shell.
5. Replace small styrofoam brick to hold power wires into the compartment. Do not connect any power wires together yet.
6. Route the antenna flat against the bottom of the shell.
7. Place upper half of shell onto lower half of shell, ensuring that the weather sensors are able to exit the side of the shell where they originally did.
8. Affix the two halves of the radiosonde shell together. Long, sturdy zip-ties (one around where the plastic strap goes, another one or two perpendicular to it over the top and bottom) would likely work well and remain intact while exposed to the potentially harsh and cold elements at high altitudes. Alternative closures could be twine (if properly tied) or hot glue, which seems to be what is used to seal the radiosonde at the factory. Glues and cements may make further re-use problematic if you intend to recover and fly the radiosonde multiple times.
9. Place the plastic strap around the radiosonde as originally equipped. You can likely push the staples back into the styrofoam if they're left intact.
10. Optionally, re-attach the paper wrapper to the payload, or feel free to attach your own wrapper or

identification.

11. Replace the plastic pins that hold the plastic strap to the radiosonde payload.
12. Ensure all sensors and antenna are extended and oriented properly. Be sure to bend the antenna into a dipole orientation similar to how it shipped (about 5.75" of the shorter lead folded back and held about 0.5" away from the twin-lead coming from the radiosonde)
13. Optionally, use a loop of tape to ensure the dipole antenna remains positioned appropriately, similar to how the antenna was originally rigged.
14. Attach radiosonde strap to flight rigging (rope/parachute/balloon or your choice of drone, kite, etc)
15. Remember to connect the red and white wires, and do a pre-flight telemetry verification immediately before launch.

Powering the radiosonde in the lab

The OEM battery bank consists of three (3) CR-123A cells in series at 3.0VDC each, for a total of 9VDC. These cells are relatively expensive and only power the unit for 6-7 hours at a time. Internal battery power is enabled by connecting the white and red power wires together inside the compartment on the bottom of the radiosonde.

The unit can be powered on the bench by providing 9VDC to the red power wire and connecting the black wire to power supply ground. Do not exceed 10VDC. Lithium-Ion rechargeable RCR-123A cells can also be used for testing. These cells will not likely last the duration of a high-altitude balloon flight due to both limited power capacity and cold temperatures at altitude.

Connectors

There are four sensor connectors (SENSN) used for sensor input by the radiosonde. SENS1 is not populated on the 403MHz units. SENS2-4 have leads connected to them, and the sensors are connected to the other end of the leads, outside of the radiosonde housing. Only SENS1 appears to have spacing for a connector; the others have arbitrary lead spacing.

SENS1 - 7-pin, 0.1" header spacing

Pin	Characteristics
1	+5V (5.47 measured) - From U25
2	GND
3	U3 Pin 37 (PA7, High Sink/20mA)
4	1 Hz - U14 (Analog MUX) Pin 9 (S2)
5	1 Hz - U14 Pin 11 (S1)
6	1 Hz - U14 Pin 11 (S0)
7	Pulldown via R41 (47k) to GND

Public information shows this header may be used for adding additional analog sensors to the radiosonde.

SENS2 - Humidity

Pin	Connection
1	Sensor pin 1
2	Sensor pin 2

0.3" spacing. Both lead wires have ferrite beads immediately before connecting to the board.

SENS3 - Temp.
Sensor (standalone)

Pin	Connection
1	Sensor pin 1
2	Sensor pin 2

0.5" spacing.

SENS4 - Temp.
Sensor (humidistat)

Pin	Connection
1	Sensor pin 1
2	Sensor pin 2

0.3" spacing. Fine gauge insulated wire run along SENS3 wire and loomed in white heat-shrink tubing.

Card edge - 40-pin, 0.100" card edge connector

Pin Number	Function	Notes / Observations	Pin Number	Function	Notes
1	Vdd	U3 - Vdd U15 - Pin 4	2	Vdd	U3 U1
3	U3 - Pin29 / PC6 / SCK / ICCCLK TP33 U21 - Pin21 / PCLK		4	U3 - Pin38/Vpp/ICCSEL	Pr ha pu Dc nil
5	U3 - Pin39/RESET		6	U3 - Pin27 / PC4 / MISO / ICCDATA	
7	Vdd	U3 - Vdd U15 - Pin 4	8	Vdd	U3 U1
9	GND		10	GND	
11	J5 - Pin 2		12	U21 - Pin 20 - DCLK	3. w da Th dir ST
13	SW1.4	U3 - Pin10/AIN3/PD3 51K resistor to ground	14		
15	GND		16	GND	
17	SW1.2	U3 - Pin8/AIN1/PD1 51K resistor to ground	18	SW1.1	U3 51
19	GND		20	GND	
21	47k pullup U3 - Pin19	Appears to be some sort of test-mode select, checked before GPIO initialization.	22		
23	GPS TX Data (38400 BPS) U3 - Pin1/RDI	Data bursts	24		+!
25			26	GPS RX Data (38400 BPS) Maybe not connected	Da

				to U3?	
27			28		
29			30	U22.3	U2 (A Cc dc Cc
31	BATT POS		32	J5 - Pin 3	
33	GND		34	GND	
35			36	SW1.3	U3 51
37			38	U3 - Pin18 / OCMP1_A / AIN10 / PF4	So bu
39	RED WIRE		40	Battery voltage	Ar m ba

Compatible connector: TE Connectivity AMP Connectors 5-5530843-4 such as Digi-Key A31723-ND[1] (<https://www.digikey.com/en/products/detail/te-connectivity-amp-connectors/5-5530843-4/770549>)

-

J1 - 4-pin, 0.1" header spacing

Pin	Wire Color	Use
1	Black	Ground
2	White	Battery +9
3	Red	+9 VDC In
4	NC	Unknown - goes to unpopulated CR1

J4 - NC - earphone jack? uses SENS3 leads

J5 - 4-pin, 2.0mm spacing

Pin	Description
1	GND
2	To (? , maybe nothing); to +5 via R7 (47k) (And Card-Edge pin 11)
3	To U3.11 (AIN4/PD4) via R47 (100); to +5 via R7 (47k) (And Card-Edge pin 32)
4	GND

SP1 - 2x4-pin, 0.1" spacing

Pin	Description	Pin	Description
1	+5VDC - All from U9	2	U14 (Analog MUX) Pin 13 (A0) - 3V rounded square pulses, 2x per second, 2 different periods avg ~75msec?
3	+5VDC	4	U14 Pin 14 (A1) - 5V, 0.1msec pulse once per second
5	+5VDC	6	U14 Pin 15 (A2) - 5V, 0.1msec pulse once per second
7	+5VDC	8	U14 Pin 12 (A3) - 3V, 250msec pulse once per second

SP1 connects to four channels of U14, an 8-channel analog MUX. Pin 2 also connects to R111, non-populated, which would provide a pull-up to +5 at Pin 1.

Components

The following is a catalog of active components. Designators italicized still need positive identification; bold have been positively identified. Markings listed where known to help in identification. List additional markings when they differ.

U1 - GPS - *Trimble 63530-50* (<https://www.trimble.com/embeddedsystems/copernicus2.aspx>) - 12-channel GPS, 2x serial ports, 2.7-3.3VDC, SBAS, flash almanac/ephemeris/location storage. (The -50 variant is probably a custom variant, and exact capabilities are unknown.)

- This chip defaults to TSIP on the 38400 baud port, which is a binary protocol, and has been captured on this PCB.
- *TSIP Protocol Documentation* (http://ftppserver.org.ru/fileecho/51_EMBED/TSIP.PDF)

U2 - (Marked G4/905)

U3 - ST72F324J6T6 - 32K Flash, 1K RAM, 5VDC, 10-bit ADC (16 inputs, muxed), 4x Timer, SPI, SCI, 32-bits total I/O

- *72F324J6T6 - ST72324 - Main Microcontroller, ST7 series Datasheet* (<http://web.archive.org/web/20200903011648/https://datasheet.octopart.com/ST72F324J6T6-STMicroelectronics-datasheet-14047.pdf>)
- *ST7 Family Programming Manual (For coders)* (https://www.st.com/resource/en/programming_manual/cd00004607-st7-family-programming-manual-stmicroelectronics.pdf)
- *ST7 Flash Programming Quick Reference Guide* (https://web.archive.org/web/20200914132209/http://www.st.com/resource/en/programming_manual/cd00054959-st7-flash-programming-quick-reference-guide-stmicroelectronics.pdf)
- *ST7 Family Flash Programming Reference Manual* ([https://www.st.com/resource/en/programming_manual/cd00004616-st7-family-flash-programming-refer](https://web.archive.org/web/20200914132013/http://www.st.com/resource/en/programming_manual/cd00004616-st7-family-flash-programming-refer))

[ence-manual-stmicroelectronics.pdf](#))

- [ST7 Family ICC Protocol Reference Manual \(https://web.archive.org/web/20200914132431/https://www.st.com/resource/en/programming_manual/cd0004617-st7-family-icc-protocol-reference-manual-stmicroelectronics.pdf\)](https://web.archive.org/web/20200914132431/https://www.st.com/resource/en/programming_manual/cd0004617-st7-family-icc-protocol-reference-manual-stmicroelectronics.pdf)
- With a buffered 16MHz clock provided by Y3/U12, possible CPU speeds are 8MHz(/1), 4MHz(/2), 2MHz(/4), 1MHz(/8) depending on MCC configuration.
- Instruction timings are in the 'ST7 Family Programming Manual'

U4 - (Marked Z252)

U5, U6 - [LP2985 \(http://web.archive.org/web/20200206204209/http://www.ti.com/lit/ds/symlink/lp2985.pdf\)](http://web.archive.org/web/20200206204209/http://www.ti.com/lit/ds/symlink/lp2985.pdf) - LDO - 2.8V?

U7 - (Marked G4/905)

U8 - (Marked G4/905)

U9 - (Marked F50)

U10 - (Did not locate, maybe not placed?)

U11 - (Marked 73RW, SOT-89 or similar) - Pre-amp for GPS ant? In GPS section can.

U12 - (Marked G5/849) - looks like a clock buffer between Y3 and U3

U13 - [CD4040BPW \(http://web.archive.org/web/20200214104034/http://www.ti.com/lit/ds/symlink/cd4040b.pdf\)](http://web.archive.org/web/20200214104034/http://www.ti.com/lit/ds/symlink/cd4040b.pdf) - 12-stage Ripple-Carry Binary Counter/Divider [\[IC Footnotes 1\]](#)

U14 - [CD74HC4051PWR \(http://web.archive.org/web/20200214042837/http://www.ti.com/lit/ds/symlink/cd74hc4051.pdf\)](http://web.archive.org/web/20200214042837/http://www.ti.com/lit/ds/symlink/cd74hc4051.pdf) - High-Speed CMOS Logic Analog Mux/Demux - 8:1

U15 - [TI LMC555CMM Family \(https://www.ti.com/lit/ds/symlink/lmc555.pdf\)](https://www.ti.com/lit/ds/symlink/lmc555.pdf) [\[IC Footnotes 2\]](#)

U16 - [LMV761MF \(http://web.archive.org/web/20190417163532/https://www.ti.com/lit/ds/symlink/lmv761.pdf\)](http://web.archive.org/web/20190417163532/https://www.ti.com/lit/ds/symlink/lmv761.pdf) - Low Voltage Precision Comparator w/ Push-Pull Output [\[IC Footnotes 3\]](#)

*U17 - (Marked Z252) - 3v(blue) -> 5v(yellow) level translator *insert picture U17 here**

U18 - (Did not locate, maybe not placed?)

U19 - (Did not locate, maybe not placed?)

U20 - [Toshiba TC7WH157FU \(https://toshiba.semicon-storage.com/info/docget.jsp?did=20148&prodName=TC7WH157FU\)](https://toshiba.semicon-storage.com/info/docget.jsp?did=20148&prodName=TC7WH157FU)

U21 - [CC1050 \(http://web.archive.org/web/20190202204556/https://www.ti.com/lit/ds/symlink/cc1050.pdf\)](http://web.archive.org/web/20190202204556/https://www.ti.com/lit/ds/symlink/cc1050.pdf) (back) - Low Power Transmitter - 300MHz-1000MHz, variable power, FSK

- [Errata \(https://www.ti.com/lit/er/swrz006a/swrz006a.pdf\)](https://www.ti.com/lit/er/swrz006a/swrz006a.pdf)


U22 - [TPS79133DBUR \(http://web.archive.org/web/20200223104004/http://www.ti.com/lit/ds/symlink/tps791.pdf\)](http://web.archive.org/web/20200223104004/http://www.ti.com/lit/ds/symlink/tps791.pdf) - 3.3V LDO - for U21

Unot_marked (23/24?) - (Marked W6K/W76) - RF Amp, similar to SKY65013-70LF (No designator; under TX can to


bottom-right of U21.)

U25 - <http://web.archive.org/web/20200123234645/https://www.ti.com/lit/ds/symlink/tps72.pdf> -
Adj. 1.2-9.75V LDO - (Designator silkscreen is hard to read; 8-SOIC on bottom-right)

Y3 - 16MHz crystal



U25 and general area



92JK ZC5 chip noted as U15

U15 Pin	Function	Observations/Notes
1	GND	
2	5VDC	
3	Trigger	Rounded square wave (maybe sawtooth) alternating between 2msec and 4msec, resting at +3VDC between bursts
4	Discharge	Rounded square wave alternating between 3msec and 5msec, short periods of 0v, resting at +3VDC between bursts
5	Output	Data. Square wave. 5V space, 0v mark? Pulses around 250msec per bit. Perhaps this is a capacitance or resistance to frequency converter.
6	Threshold	More rounded square wave bursts
7	Reset	
8	Control	

Sens 4 - Capacitive Relative humidity sensor [\[IC Footnotes 4\]](#)

Notes

1. Package marking shows CM040B. TI Park marking lookup provides CD4040BPW.
2. IC marked with ZC5. TI Part marking lookup provides LMV761. Pinout, footprint, and measured IC/pin operation matches what is expected from a 555.
3. Package marking shows C22A. TI Part marking lookup provides LMV761. The SOT-23 footprint appears to match what is on the PCB.
4. Sens 4 is known to be capacitive since it is listed as such on page 13 of the [WMO Common Code Tables Document](https://web.archive.org/web/20200619153019/https://www.wmo.int/pages/prog/ww/WMOCodes/WMO306_v12/LatestVERSION/WMO306_v12_CommonTable_en.pdf) (https://web.archive.org/web/20200619153019/https://www.wmo.int/pages/prog/ww/WMOCodes/WMO306_v12/LatestVERSION/WMO306_v12_CommonTable_en.pdf)

GPS Subsystem

Trimble 63530 baud rate is 38400, 5V, connected to ST7 SCI port(Pins 1&2 on ST7, TDO and RDI). Assuming 8N1 framing, this means interrupts must not be disabled for >260 microseconds or else bytes may be lost as the receive shift register overflows.

Pin	GPS	GPS Name	Goes to
1		GND	ground
2		GND	ground (separated to RF subsystem)
3		RF-IN	Passives, then GPS antenna
4		GND	ground
5		LNA	nothing visible
6		VBAT	nothing visible
7		Open	To VCC3 via C1 & C3
8		Short	VCC3 - should be high
9		Reserved	VCC3
10		Reserved	VCC3
11		Xreset	VCC3
12		Vcc	VCC3 - C2 bypass to GND at pin 13
13		GND	ground
14		GND	ground
15		GND	ground
16		Xstandby	VCC3
17		Reserved	nothing visible
18		Reserved	nothing visible
19		PPS	C9 bypass to GND, Via to back to trace to via to small via connected to R3, then trace to 47k to ground, then some pins on U2 - looks like a level translator - through that then to a hidden via, pops back up at TP36 which is connected to PB4 on the ST7, which triggers ei3(external interrupt 3) in the firmware.
20		RXD-B	appears unused
21		RXD-A	comes from U4 level translator, splits to pin 24 on edge connector then 10k resistor to Pin16 on ST7 which is PF1
22		Reserved	
23		TXD-A	38400 baud to the ST7 RDI/Pin1/PE1
24		TXD-B	4800 baud appears unused
25		Reserved	
26		Reserved	

27	GND	ground	
28	GND	ground	

GPS xSTANDBY - connected to 3.3v

GPS xRESET - connected to 3.3v

CC1050 Subsystem

CC1050 Pin	CC1050 Name	ST7 Pin	Notes/Observations
19	DI	Pin18 / OCMP1_A / AIN10 / PF4	U17 appears to be a level translator between CC1050.19 and ST7.18
20	DCLK	Pin30 / PC7 / SS / AIN15	U7 appears to be a level translator between CC1050.20 and ST7.30
21	PCLK	Pin29 / PC6 / SCK / ICCCLK	
22	PDATA	Pin28 / PC5 / MOSI / AIN14	Voltage varies between 5 and 3.something volts depending on which side is transmitting.
23	PALE	Pin27 / PC0	

CC1050 Frequency Register Calculator based on 14.7456MHz crystal (<https://github.com/rsaxvc/LMS6APRS/blob/master/docs/cc1050%20frequency%20calculator.ods?raw=true>)

Link to SmartRF Studio6 (7 doesn't have the CC1050) (<https://e2e.ti.com/support/wireless-connectivity/zigbee-and-t-hread/f/158/t/158428?Where-can-one-find-SmartRF-Studio-6->)

Test Points


TP58 - MUX in/out (U14 Pin 3)

Circuits

RF Transmitter Circuit

The transmitter RF path contains a filter IC, pi matching network, broadband amplifier, and a few more output filter

stages.




Low Pass Filters

Lowpass Filters are included on the output from the PA and CC1050 to filter out spurs and harmonics from the signal. These are required to meet FCC and NTIA (<https://www.ntia.doc.gov/>) emissions requirements. The measurements were taken with a NanoVNA V2 (<https://nanorfe.com/nanovna-v2.html>) and the plots were acquired using the NanoVNA-QT software (<https://github.com/nanovna/NanoVNA-QT/releases>). These data should be considered uncalibrated. A S11 calibration OPEN,SHORT was performed on the NanoVNA, but since the coax is cut, I did not

perform an S21 calibration. Additionally, the NanoVNA-QT software seemed to blowaway any of the manual settings I had. This software does not seem to support an OPEN/SHORT only calibration. These data can safely be interpreted as realtive measurements, meaning the filter type and cutoff frequency can be determined.

PA LPF


The PA LPF was measured by removing the DC blocking capacitor after the RF amplifier in the schematic above. The removed DC blocking capacitor is Port 1 of the measurement. Port 2 of the measurement is the antenna output with the antenna removed. The 3 dB cutoff of the filter is 500 MHz.




Lowpass filter output from the power amplifier. The blue trace is the S11 plot. The red trace is the S21 plot. This is from 200 MHz to 1.425 GHz. Absolute values are not to be trusted. The relative measurement indicates that the 3 dB cutoff of the filter is around 500 MHz.

FL101 - CC1050 LPF

The FL101 frequency response was measured as shown below. A DC blocking capacitor was removed that was between the output of CC1050 and FL101. Two parallel resistors were removed from the output of FL101. This isolated the filter in the circuit. The cutoff of the filter is 650 MHz.




Lowpass filter FL101, output from the CC1050. The blue trace is the S11 plot. The red trace is the S21 plot. This is from 200 MHz to 1.425 GHz. Absolute values are not to be trusted. The relative measurement indicates that the 3 dB cutoff of the filter is around 650 MHz.



Test setup for the FL101 measurement.

Relative Humidity Circuit



Schematic of RH sensor circuit.

Analog Multiplexer

U14 is an 8-channel mux/demux.

- Four of the channels (A0-A3) go to SP1.
- (A4-A7 appear to go to SENS2-4, need to be traced)
- Pin 3 is the common in/out and goes to R13 (560k) and R15 (47k). R15 goes to U15 Pin 7 (555

Reset), and R13 goes to U15 Pin 8 (555 Control.)

- Address Select 0 is connected to ST7 Pin 2 / PB0
- Address Select 1 is connected to ST7 Pin 3 / PB1
- Address Select 2 is connected to ST7 Pin 4 / PB2

Original Firmware

Original firmware is not locked and can be dumped with Rlink-STD Debugger with RFlasher7.

Several dumps are publicly available on <https://github.com/MrARM/lms6/tree/master/dumps>

Vector table and other interesting addresses:

- 0x9CDB - The start of frequency registers, each dip switch has registers starting from this address.
- 0xE003 - Serial number, at least 3 bytes. Ex: 0x7C6A34 is 8153652 big-endian.
- 0xE100 to 0xE136 - something that changes between units. Maybe calibration factors? Checksums?
- 0xFF00 - software string. Ex: "May 17, 2017 - V1.45"
- 0xFFE4 - AVD vector
- 0xFFE6 - SCI / UART vector
- 0xFFE8 - Timer B vector
- 0xFFEA - Timer A vector
- 0xFFEC - SPI vector
- 0xFFEE - vector unused on this chip
- 0xFFFF0 - EI3 vector
- 0xFFFF2 - EI2 vector
- 0xFFFF4 - EI1 vector
- 0xFFFF6 - EI0 vector
- 0xFFFF8 - MCC/RTC vector
- 0xFFFFA - vector unused on this chip
- 0xFFFFC - Trap vector
- 0xFFFFE - Reset vector

IDA Pro uses CPU type ST7->ST72324J6 during loading, and can load the Intel Hex file produced by the programmer directly for analysis.

Option Bytes

Option bytes are set to 0xE7F7

Original Firmware Option Byte Details

Option Description	Original Setting
Watchdog Reset on Halt (Reset On Entering Halt)	Reset generation when entering HALT mode
Hardware of Software Watchdog	Software (watchdog to be enabled by software)
Low Voltage Detection Selection (LVD Config)	Highest Voltage Threshold
FLASH read-out protection	Read-out protection disabled
Package selection	(A)R - TQFP64
RESET clock cycle selection	Reset phase with 256 CPU cycles
Oscillator Type	External Source
Oscillator Range	HS 8~16MHz
PLL activation	PLL x2 disabled

GPIO Initialization

- PADDR = 0xF0, PAOR = 0x38 or 0x30 depending on address 0xF3
 - PA7: Open Drain Output
 - PA6: Open Drain Output
 - PA5: Push Pull Output
 - PA4: Push Pull Output
 - PA3: Depends on address 0xF3
- PBDDR = 0x0F, PBOR=0x1F
 - PB4 - Pullup interrupt input
 - PB3 - Push Pull Output
 - PB2 - Push Pull Output
 - PB1 - Push Pull Output
 - PB0 - Push Pull Output
- PCDDR = 0x03, PCOR=0x0B
 - PC7 - floating input
 - PC6 - floating input
 - PC5 - floating input
 - PC4 - floating input
 - PC3 - pullup input
 - PC2 - floating input
 - PC1 - push pull output
 - PC0 - push pull output
- PDDDR = 0x20, PDOR=default to 0x0
 - PD5 - open drain output
 - PD4 - floating input
 - PD3 - floating input
 - PD2 - floating input
 - PD1 - floating input

- PD0 - floating input
- PFDDR = 0x20 or 0x80 depending on address 0xF3, PFOR=0x10 or 0x80 depending on address 0xF3
 - PF7 - depends on 0xF3
 - PF6 - floating input - is checked very early on startup and used to set 0xF3. 47k resistor to 5v, TP8, CardEdge21.
 - PF5 - depends on 0xF3
 - PF4 - depends on 0xF3
 - PF2 - floating input
 - PF1 - floating input
 - PF0 - floating input

MCC Initialization

Done in the main function, MCCSR is initialized to 0x0E. This means:

- Clock Prescaler[CP] is set to /2
- SlowModeSelect[SMS] is set to 0, so CP is ignored and Fcpu=Fosc2
- TimeBase[TB] is 0b11, selecting 25ms timebase
- OscillatorInterruptEnable[OIE] is set, has something to do with low-power mode(s)
- OscillatorInterruptFlag[OIF] is clear, indicates main oscillator has reached countdown

MCCBCR does not appear to be initialized, meaning beeper-mode is disabled.

ADC Configuration

ADCDRL does not appear to be used, thus the ADC is operated as an 8-bit ADC instead of 10-bit.

ST7 ADC AIN8 appears to be the only one used.

Interrupts

- ei0_int
 - Triggered by PortA.3
 - uses location 0xB2 as a shift register to output LSB first to CC1050's Data Input on PortF.4
- ei3_int
 - Triggered by PortB.4
 - Sets a variable when GPS PPS occurs

GPS Initialization

On startup, the ST7 sends the following TSIP(0x10 then 0xID, then data with 0x10 double-escaping, then 0x10,0x03) packets to the GPS.

- 0x10, 0x8E, 0x2A, 0x01, 0x10, 0x03 - Request Fix and Channel Tracking Info, Type 1

- 0x10, 0x8E, 0x26, 0x10, 0x03 - SAVE SEEPROM
- 0x10, 0x8E, 0x2B, 0x01, 0x10, 0x03 - Request Fix and Channel Tracking Info, Type 2
- 0x10, 0x8E, 0x26, 0x10, 0x03 - SAVE SEEPROM

Modifications


Disable amplification

When testing, it's important not to transmit on unlicensed frequencies. Emissions can be eliminated by replacing the RF amplifier with a jumper between pins 1 and 3, and terminating the load at the antenna connection. The amplifier is an SOT-89 device just above the "-" terminal of B3. To access the RF chain, the shield housing may need to be temporarily removed. Also remove the bias feed resistor just below the "L104" marking. Then, remove the transmitter antenna from the "ANT1" connections. Use a 50 ohm resistor across the two terminals to provide a terminating load and eliminate any further transmission. Near-field reception is still possible after making these changes.

Change Frequency^[1]

It is possible to change the TX frequency by modifying what is sent to the cc1050(radio) registers. Here is an example on how to get 422.5 MHz

1. Download this frequency calculator:
<https://github.com/rsaxvc/LMS6APRS/blob/master/docs/cc1050%20frequency%20calculator.ods>
2. The easiest way to get started is to edit NWS1111's frequency(row 17), delete column D and J.
3. Change column J to your desired frequency(for this example, 422.500000). Try to keep your frequency close to the original if you want to only have to change the frequency register.
4. A number in column I will appear, copy this number to column D and round it up.
5. Start gradually adjusting column D until the frequency error (col. K) is around ± 5
6. Convert your number in column D to hexadecimal
7. Acquire a dump of your LMS-6 firmware using a programmer
8. Go to 0x9D8F in the dump in a hex editor and insert the first two bytes of your hexadecimal number. Insert the next two after the 05 byte and the final two after the 07 byte.
9. Save this hex file and flash it to the LMS-6
10. Set all dip switches to 1 1 1 1 and turn on your LMS-6, you should be able to see it transmitting in your desired frequency. If you see abnormalities with the waveform, make sure your Freq Err is good, and check your FSEP and REFDIV values.



Picture of TX circuit, highlighting components to remove to disable amplifier and a replacement jumper.

Instruction Timing Tables

These are based on the ST Visual Develop 4.3.12 Simulator. Hopefully it is accurate. I've only done the instructions needed for writing a software UART, since the hardware UART is tied up doing GPS work.

instruction	cycles	Purpose	condition tested
sim	2	Set instruction mask(disable interrupts)	
nop	2	no-op	
bres	5	bit-reset	;reset a GPIO pin BRES PADR, 0
bcp	2	bit-compare	BCP A,0
jreq	3	jump	jump not taken jump taken
bset	5	bit-set	;set a GPIO pin BSET PADR, 0
jrt	3	jump "right there"?	
ld	2	load register/memory to/from register/memory	LD A, X

Ideas for doing AFSK modulation on 70CM with CC1050 and ST7

The goal is to draw an approximation of a sine-wave over time in the frequency domain. This is usually done by drawing a sine-wave with a DAC, low-pass filtering it, and feeding it into an FM modulator, but we don't have those parts.

FeatherHAB Approach using a similar FSK chip

The FeatherHAB approach involves using a transmitter with an asynchronous digital modulation input(CC1050 can do this), and oversampling it like a 1-bit DAC. I think this works as long as the input signal is much faster than the charge pump bandwidth, and if so, it should act like a low-pass filter. FeatherHAB uses a hardware timer to drive their digital modulation input, but they do so by sending a variable-length pulse every 19200 Hz.

We might be able to do this using a 19200Hz periodic timer interrupt to set the modulation pin and a one-shot timer to generate another interrupt to clear it. This will use all available timers on the ST7. We cannot use a timer to generate the pulses directly as the ST7 does not wire out any timers on the right pins.

SFCW-like Frequency Hopping Approach(RSAXVC)

The CC1050 has a pair of frequency register sets, this allows programming a new frequency then flipping to it using a

bit - this takes 4x register writes(16 bits each). We could, like a stepped frequency radar, switch between a series of tones rapidly(perhaps 8x symbol rate). This would look like an unfiltered DAC version of a sine-wave with little stair-steps.

Why we're not going to do 9600baud 70CM FSK modulation

For these to be a usable tracker we're going to need ground stations. In the Kansas City metro, there's not many APRS digipeaters on 70cm, and the few there are use 1200 baud AFSK, not 9600 baud FSK.

ST7 Programming

The ST7 can be programmed using the RLINK-STD programmer. This programmer is available from Digi-Key <https://www.digikey.com/en/products/detail/iotize/RLINK-STD/9923059>

FlashBash Programmer

The FlashBash ST7 programmer claims to be able to program the ST7 on the LMS-6. This has not been evaluated yet. <http://www.spen-soft.co.uk/>

FlashBash V3 PCB can be ordered from DirtyPCBs.com: <https://dirtypcbs.com/store/designer/details/1826/6489/flashbash-v3-st7-programmer>

LMS-6 Card Edge Interface

LMS-6 Card edge interface board KiCad schematic and board layout: https://github.com/Reid-norc/LMS-6_Interface_Board

LMS-6 Card Edge Interface PCB Rev B can be ordered from DirtyPCBs.com: <https://dirtypcbs.com/store/designer/details/1826/6490/lms6-interface-board-rev-b>

LMS-6
Card
Edge
Connector
Digi-Key
BOM
[\[Expand\]](#)

Interface Description and Theory of Operation

The LMS-6 interface PCB allows the LMS-6 to be powered, connect to USB to UART, and connect to an in circuit programmer through the card edge connector.

Power Jumper Settings

Jumper Ref Des	Jumpered Pins			
	Battery	USB 5V	Banana Jacks Regulated (J1&J3)	Direct Power (J11&J12)
J2	X	2,3	1,2	X
J6	1,2	2,3	2,3	2,3
J10	X	2,3	2,3	1,2

LMS-6 Interface Board Schematic Rev 10 (https://github.com/Reid-norc/LMS-6_Interface_Board/blob/main/LMS-6_Interface_Board_Rev_10.pdf)

Circuit Power Options

The LMS-6 Inteface board offers four power options to power LMS-6. Components for any of the power options can be omitted if they will be unused to reduce the build the build cost.

Battery Power

The LMS-6 can be powered using three CR123 lithium batteries connected to the LMS-6 onboard battery holders. Batter power is enabled by jumpering Pin 1 and Pin to of J6 together.

USB 5V Power

The LMS-6 can be powered from the J4 Micro USB B connection. This is enabled by jumpering Pin 2 and Pin 3 of J2; Pin 2 and Pin 3 of J6.

USB power is indicated by D2 Green LED

USB to UART

The LMS-6 interface includes a FT-2232 USB to UART. UART1 is connected to GPS. The default baud rate for the GPS is 38400 bps. UART 2 TX is connected to U3 pin 19 on the LMS-6.

If the connections are wrong, they can swapped using JP1,JP2 and JP4, JP5.

In Circuit Programming

eFuse

Reference

Here are some reference materials. This is an initial population of material, and this section will need significant cleanup - putting links up for now.

https://www.weather.gov/media/upperair/Documents/RWS_Build_3.4_User_Manual_%20071818.pdf - Radiosonde Replacement System Workstation User Guide. This manual describes the operational environment of the radiosonde.

<https://www.nws.noaa.gov/directives/010/pd01014001b.pdf> - Rawinsonde Operations - some more technical data on radiosonde operations.

References

1. <https://github.com/MrARM/lms6#change-the-tx-frequency>
-

Retrieved from "https://wiki.recessim.com/w/index.php?title=LMS-6_Radiosonde&oldid=1551"

This page was last edited on 20 November 2021, at 03:13.

Content is available under [Creative Commons Attribution-ShareAlike](#) unless otherwise noted.